LENA State Log

time (UT)	<u>event</u>
00 085 21:30:34 (25 Mar)	launch
087 06:00 (27 Mar)	instrument on –liveness test
18:00	instrument off
112 16:13 (21 Apr)	instrument on
115 14:40 (24 Apr)	set overcount threshold to 2AF8
14:52	HVPS unsafed
14:53	normal mode implemented
15:03	voltage thresholds to AA AA 74 74 51
15:04	current thresholds to FFx5
15:14	start/stop CFDs to level 8
15:19	start/stop MCPs to level 0
15:30	start/stop MCPs enabled
15:37	start/stop MCPs to level 20
15:44	start/stop MCPs to level 40
15:51	start/stop MCPs to level 50
16:01	start/stop MCPs to level 60
16:08	voltage thresholds to D5 D5 91 91 73
16:09	start/stop MCPs to level 70
16:17	start/stop MCPs to level 80
16:31	start/stop MCPs to level 88
16:42	start/stop MCPs to level 90
116 03:20 (25 Apr)	overcount pushes start/stop MCPs to level 7C
16:28-18:36 (?)	overcount pushes start/stop MCPs to level 72
119 12:12 (28 Apr)	start/stop MCPs to level 80
12:19	start/stop MCPs to level 88
12:23	start/stop MCPs to level 90
12:40	coll plus/coll minus to level 0
12:53	coll plus/coll minus enabled
13:00	coll plus/coll minus to level 10 (+/- 2.4)
13:13	coll plus/coll minus to level 20 (+/- 2.7)
13:27	coll plus/coll minus to level 30 (+/- 3.2)
13:46	coll plus/coll minus to level 40 (+/- 3.6)
13:59	coll plus/coll minus to level 50 (+/- 4.1)
14:07	coll plus/coll minus to level 60 (+/- 4.4)
14:24-18:14	overcount pushes start/stop MCPs to level 72 and coll plus/minus to leve
19:07	set overcount threshold to FFFF (disabled)
19:11	start/stop MCPs to level 80
19:19	start/stop MCPs to level 88
19:29	start/stop MCPs to level 90
120 18:42 (29 Apr)	start/stop CFDs to level 2/6 (Denver levels)

122 23:51 (1 May)	stop MCP to level 50
23:59	stop MCP to level 60
123 00:06 (2 May)	stop MCP to level 70
00:17	stop MCP to level 80
124 01:40 (3 May)	optics to level 0
01:48	optics enabled
02:08	optics to level 10
02:21	optics to level 20
02:38	optics to level 30
03:00	optics to level 40
03:14	optics to level 50
03:32	voltage thresholds to D5 D5 91 91 86
03:45	optics to level 60
04:13	optics to level 68
04:33	voltage thresholds to D5 D5 91 91 97
04:38	optics to level 70
04:53	optics to level 78
126 21:13 (5 May)	set position sensing to low gain
148 11:07 (27 May)	set steering controller to level 0
11:13	enabled steering controller stepping table
11:23	disabled steering controller stepping table
11:33	set steering controller to level 20
11:43	set steering controller to level 40
12:05	set steering controller to level 60
12:25	set steering controller to level 80
155 02:52 (3 June)	redefine mass 1 bin to 27-2B
02:54	stop MCP to level 90
03:53	coll plus/coll minus to level 10 (+/- 2.4)
04:07	coll plus/coll minus to level 20 (+/- 2.7)
04:22	coll plus/coll minus to level 30 (+/- 3.2)
04:37	coll plus/coll minus to level 40 (+/- 3.6)
04:52	coll plus/coll minus to level 50 (+/- 4.1)
05:10	coll plus/coll minus to level 60 (+/- 4.4)
16:40	*** all S/I's including LENA safed ***
156 18:33 (4 June)	instrument on
18:56	HVPS unsafed
18:57	normal mode implemented
19:02	voltage thresholds to AA AA 74 74 51
	current thresholds to FFx5
10.00	MCP's, optics and coll to level 0
19:08	MCP's, optics and coll enabled
19:43	set overcount threshold to FFFF (disabled)
19:51	start/stop CFDs to level 2/6 (Denver levels)
19:53	set position sensing to low gain
19:53	set steering controller to level 0
19:55	redefine mass 1 bin to 27-2B

20:03	MCP's to level 20, coll/optics to level 10
20:11	MCP's to level 40
20:22	MCP's to level 50
157 18:06 (5 June)	coll/optics to level 20
18:12	MCP's to level 60
18:21	voltage thresholds to D5 D5 91 91 73
18:21	MCP's to level 70, coll/optics to level 30
18:42	MCP's to level 80, coll/optics to level 40
18:53	start MCP to level 88
19:00	coll/optics to level 50
19:06	start MCP to level 90
158 22:29 (6 June)	voltage thresholds to D5 D5 91 91 86
22:29	optics to level 60
22:39	optics to level 68, coll to level 60
22:48	voltage thresholds to D5 D5 91 91 97
22:49	optics to level 70
23:34	optics to level 78
23:40	stop MCP to level 88
23:47	stop MCP to level 88 stop MCP to level 90
	*** start of uploaded commanding ***
159 10:10 (7 June)	redefine mass bin 1 to 0-7F and mass bin 2 to 80-FF
161 22:00 (9 June) 22:01	
	stop MCP to level 90
169 12:10 (17 June)	*** all S/I's including LENA safed ***
172 02:07 (20 June)	instrument on
02.27	
02:27	HVPS unsafed
02:27	normal mode implemented
	normal mode implemented voltage thresholds to AA AA 74 74 51
02:27	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5
02:27 02:32	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0
02:27 02:32 02:38	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled
02:27 02:32 02:38 173 03:01 (21 June)	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10
02:27 02:32 02:38 173 03:01 (21 June) 03:07	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled)
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels)
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08 03:10	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels) set position sensing gain to low
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08 03:10 03:15	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels) set position sensing gain to low MCP's to level 40
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08 03:10 03:15 03:24	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels) set position sensing gain to low MCP's to level 40 MCP's to level 50
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08 03:10 03:15	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels) set position sensing gain to low MCP's to level 40 MCP's to level 50 coll/optics to level 20
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08 03:10 03:15 03:24	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels) set position sensing gain to low MCP's to level 40 MCP's to level 50 coll/optics to level 20 MCP's to level 60
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08 03:10 03:15 03:24 03:30	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels) set position sensing gain to low MCP's to level 40 MCP's to level 50 coll/optics to level 20 MCP's to level 60 voltage thresholds to D5 D5 91 91 73
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08 03:10 03:15 03:24 03:30 03:37	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels) set position sensing gain to low MCP's to level 40 MCP's to level 50 coll/optics to level 20 MCP's to level 60
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08 03:10 03:15 03:24 03:30 03:37	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels) set position sensing gain to low MCP's to level 40 MCP's to level 50 coll/optics to level 20 MCP's to level 60 voltage thresholds to D5 D5 91 91 73
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08 03:10 03:15 03:24 03:30 03:37 03:45	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels) set position sensing gain to low MCP's to level 40 MCP's to level 50 coll/optics to level 20 MCP's to level 60 voltage thresholds to D5 D5 91 91 73 MCP's to level 70, coll/optics to level 30
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08 03:10 03:15 03:24 03:30 03:37 03:45	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels) set position sensing gain to low MCP's to level 40 MCP's to level 50 coll/optics to level 20 MCP's to level 60 voltage thresholds to D5 D5 91 91 73 MCP's to level 70, coll/optics to level 30 MCP's to level 80, coll/optics to level 40 MCP's to level 88 coll/optics to level 50
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08 03:10 03:15 03:24 03:30 03:37 03:45	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels) set position sensing gain to low MCP's to level 40 MCP's to level 50 coll/optics to level 20 MCP's to level 60 voltage thresholds to D5 D5 91 91 73 MCP's to level 70, coll/optics to level 30 MCP's to level 80, coll/optics to level 40 MCP's to level 88
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08 03:10 03:15 03:24 03:30 03:37 03:45 03:53 04:01 04:11	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels) set position sensing gain to low MCP's to level 40 MCP's to level 50 coll/optics to level 20 MCP's to level 60 voltage thresholds to D5 D5 91 91 73 MCP's to level 70, coll/optics to level 30 MCP's to level 80, coll/optics to level 40 MCP's to level 88 coll/optics to level 50
02:27 02:32 02:38 173 03:01 (21 June) 03:07 03:08 03:10 03:15 03:24 03:30 03:37 03:45 03:53 04:01 04:11 04:17	normal mode implemented voltage thresholds to AA AA 74 74 51 current thresholds to FFx5 MCP's, optics and coll to level 0 MCP's, optics and coll enabled MCP's to level 20, coll/optics to level 10 set overcount threshold to level FFFF (disabled) start/stop CFDs to level 2/6 (Denver levels) set position sensing gain to low MCP's to level 40 MCP's to level 50 coll/optics to level 20 MCP's to level 60 voltage thresholds to D5 D5 91 91 73 MCP's to level 70, coll/optics to level 30 MCP's to level 80, coll/optics to level 40 MCP's to level 88 coll/optics to level 50 MCP's to level 90

04:34	voltage thresholds to D5 D5 91 91 97
	optics to level 70
04:38	optics to level 78
04:43	optics to level 80 (12.1 kV)
15:46	*** start of uploaded commanding ***
176 05:14 (24 June)	HVPS error flag reset (no impact error)
180 19:55 (28 June)	HVPS error flag reset (no impact error)